

INSTALLATION INSTRUCTIONS FOR AL-03 SERIES PAGODA AREA LIGHTS

1. Thread mounting device onto base of fixture.

If using FA-03-LG or FA-04, press into ground and connect to main cable. We recommend using our FA-05 Quick Connector.

If FA-01, make sure the base PVC is free of dirt to allow the inner tube to be adjusted as needed. A set screw is provided to set desired height.

If using FA-25, you must dig a 6"-8" diameter hole, 10"-14" deep. Loop main cable to stake or run fixture wire out of the bottom to the main cable. Make connection then back fill hole and wiring.

If using FA-22 or FA-24 canopies, secure with appropriate screws for mounting surface.

2.

2. All AL-03 Series lights are supplied with lamps installed. To remove single contact lamps; turn off power, let cool down, push and turn counter clockwise, then pull outward and away from socket. It is recommended to lubricate lamp screw shell (not lamp contact) with dielectric or lithium grease for ease of service and future maintenance. For T-3 Bi-Pin Halogen and Xenon lamps; turn power off, let cool down, pull outward and away from socket.


NOTE: All mounting stakes can be pressed or hammered into the ground with a standard hammer or rubber mallet. We recommend our Focus FT-01 stake installation tool (see below). Always leave the top 1" section of the stake above ground to help isolate the metal from potentially corrosive soils. Fixture wire (18/2) should be buried underground to prevent detachment. For a more permanent mount, you can set the stake in concrete or use our FA-25 Commercial mounting pedestal.

LAMP INSTALLATION / REPLACEMENT

Turn off power before installing or servicing fixtures.

CAUTION: Do not exceed maximum wattage marked on fixture label.

To re-lamp, first let light bulb cool down prior to touching. Loosen set screw on adjustable hub and slide top up and off of stem. Push S.C. base light bulb into socket and turn counter clockwise to release, then pull up and out of socket. Check label under top for correct size and wattage S.C. base light bulb. Insert new S.C. base light bulb into socket by pushing down and rotating clockwise. Replace top and tighten set screw on adjustable hub at desired height. Turn on power supply to fixture and check for proper connection and operation.



12v Install AL-18-SM 112311