

INSTALLATION INSTRUCTIONS FOR 12v SL-45 MINI FLOOD LIGHT


INSTALLATION FOR SL-45

NOTE: To prevent electrical shock, disconnect transformer from electrical supply before installation or service.

- 1. Loosen two thumb screws that attach the U-bracket to the fixture and remove U-bracket.
- 2. Using U-bracket as a templete, mark hole for location of mounting screw.
- 3. Drill pilot hole for one #6 mounting screw.
- 4. Using a Phillips #2 screwdriver mount U-bracket to surface with supplied 1 inch #6 mounting screw.
- 5. Attach fixture to U-bracket with two thumb screws, rotate fixture to desired angle and hand tighten thumb screws.

NOTE: Lead wire can be attached to surface using staples or a hole can be drilled to pull wire through the back of surface to hide wiring. For cleaner installation, we recommend using the Focus FA-111-SM Junction box.

- 6. Route lead wire to main 12V supply cable and make connection. We recommend our **FA-05** Quick Connector (sold separately.)
- 7. Provide 12V power to fixture and check for proper operation.



LAMP INSTALLATION/REPLACEMENT

- 1. Turn off power.
- 2. Remove two (2) screws closest to the bottom base (flat side) of the fixture using a #2 Phillips screwdriver
- 3. Holding onto bottom base and sides of housing gently pull housing off of the base. Be careful not to touch or put pressure on the lens.
- 4. Pull Bi-Pin light bulb away from socket to release. Replace with correct Bi-Pin light bulb type and wattage marked on fixture label.
- 5. Reinstall housing onto base and tighten two (2) screws to secure housing.

CAUTION: Do not exceed maximum wattage marked on fixture label.

IMPORTANT SAFETY INSTRUCTIONS TO REDUCE THE RISK OF FIRE AND INJURY TO PERSONS:

1. Lamp gets hot quickly; turn off, unplug/disconnect and allow to cool down before replacing the light bulb.

- 2. DO NOT touch hot lens, use guard or enclosure.
- 3. DO NOT look into lamp when on.
- 4. Keep lamp away from materials that may burn.
- 5. Use only with wattage/lamp marked on fixture warning and instructions.
- 6. Use the correct light bulb base with the correct socket.
- 7. **DO NOT** touch lamp at anytime. Use a lint-free cloth when handling the Halogen light bulbs as oil from skin may damage lamp and shorten lamp life.
- 8. **DO NOT** operate fixture with missing or damaged shield or lens.